

H18.7.5時点(VVTiマップ)

回転数

400rpm 800rpm 1200rpm 1600rpm 2000rpm 2400rpm 2800rpm 3200rpm 3600rpm 4000rpm 4400rpm 4800rpm 5200rpm 5600rpm 6000rpm 6400rpm 6800rpm 7200rpm 7600rpm 8000rpm

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20

負荷軸

1	60	60	60	60	60	60	60	60	60	60	60	60	60	60	60	60	60	60	60
2	60	60	60	60	60	60	60	60	60	60	60	60	60	60	60	60	60	60	60
3	52	52	53	53	53	53	54	54	55	55	57	57	60	60	60	60	60	60	60
4	40	40	40	36	39	42	47	50	53	53	57	57	60	60	60	60	60	60	60
5	21	21	30	34	38	41	41	48	48	48	57	57	60	60	60	60	60	60	60
6	17	18	27	33	35	39	37	44	45	47	57	57	60	60	60	60	60	60	60
7	15	15	24	33	35	36	35	39	42	43	55	57	60	60	60	60	60	60	60
8	10	12	21	30	33	34	34	38	41	43	48	57	59	60	60	60	60	60	60
9	10	10	15	27	30	34	33	36	41	43	48	57	59	60	60	60	60	60	60
10	10	10	15	23	27	32	31	34	39	43	48	57	59	60	60	60	60	60	60
11	10	10	15	20	25	29	29	32	36	42	48	54	57	60	60	60	60	60	60
12	10	10	15	20	25	28	28	30	34	42	48	54	57	60	60	60	60	60	60
13	10	10	15	20	25	28	28	30	34	42	48	54	57	60	60	60	60	60	60
14	10	10	15	20	25	28	28	29	34	42	48	52	55	60	60	60	60	60	60
15	10	10	15	20	25	28	28	29	34	42	48	52	55	60	60	60	60	60	60
16	10	10	15	20	25	28	28	29	34	42	48	52	55	60	60	60	60	60	60
17	10	10	15	20	25	28	28	29	34	42	48	52	55	60	60	60	60	60	60
18	10	10	15	20	25	28	28	29	34	42	48	52	55	60	60	60	60	60	60
19	10	10	15	20	25	28	28	29	34	42	48	52	55	60	60	60	60	60	60
20	10	10	15	20	25	28	28	29	34	42	48	52	55	60	60	60	60	60	60

変更箇所

コメント:ログデータからブースの落ち込みが見られたのでデフォルトに戻してみた